

## Installation Instructions

**Thank you** for purchasing the Upholstery Clip by TACO Marine. Since 1959, we have taken great pride in offering the highest-quality products with excellent customer service. We stand behind our products 100 percent. Please visit our website [tacomarine.com](http://tacomarine.com) for more detailed information on a wide variety of products and to register your new accessory for warranty.

1. Screw clips onto desired surface.
2. Hold the panel in place, so that the holes in the clips line up with those in the mounting surface.
3. Set the panel in place. Insert the screws through the collars, thread the screws into the screw holes just enough to hold the panel in place, Check the panel again for fit and placement.
4. Adjust the panel as necessary; tighten all the screws.
5. Insert upholstered panel into clips.

### Box Includes

- UPHOLSTERY CLIP

### Required\* \*not included

- SCREW DRIVER
- STAINLESS STEEL SCREWS WITH COLLARS

