Ultrafabrics.

General Cleaning Instructions for Ultrafabrics[®] Products^{*}

One of the best ways to keep all Ultrafabrics, LLC brand surfaces looking great is to properly maintain them by cleaning regularly to prevent excessive dirt from accumulating. Below is a general outline to help you keep your quality Ultrafabrics brand products looking their best.

Following these guidelines will help to extend the life of the fabric:

- Clean regularly with soap and water.
- Wipe up spills as soon as they occur.
- Alcohol based cleaners such as Fantastik® and Formula 409°.
- Sanitize using disinfectants such as bleach (20%) water solution, hydrogen peroxide based, or quaternary based.*
- For stubborn stains, wipe the stain off with isopropyl (rubbing alcohol) as soon as possible.
- Thoroughly rinse all solution residue with clean water.
- Air dry.

Consult the furniture manufacturer's cleaning guidelines for further care. *For further details, please contact your sales agent.

Indoor/Outdoor Maintenance Instructions^{*}

- All Ultrafabrics Indoor/Outdoor products should be stored in a dry, well ventilated area.
- Ultrafabrics mildew resistant surfaces do not promote mildew growth, however, mildew may grow on dirt and other foreign substances that are not removed from the fabric.
- The frequency of cleaning will vary greatly depending upon the local outdoor environment in which the product is used.
- Cushions should not remain wet or be covered, as this will increase the chances of mildew growth occurring.
- All of our Indoor/Outdoor products perform best when they are paired with an open cell, reticulated, quick drying foam and/or a waterproof, anti-mildew barrier between the fabric and foam and utilize air vents and/or a mesh, open weave fabric bottom.

Ultraleather[™] Pro Tough Stain Instructions^{*}

	MARKET	STAIN	
I	Restaurant & Food Service	Ketchup, Mayo, Mustard*, Coffee, Red Wine, Tea	CLEANING INSTRUCTIONS
-	Healthcare	Blood, Urine, Betadine	Clean with alcohol based cleaners, like Formula 409 [®] , or 5:1 water/bleach solution. *For tough stains clean using isopropyl/rubbing alcohol. After cleaning, rinse surface with clean water and wipe dry. Prompt attention is important for successful removal of any stain.
(Contract & High Traffic Areas	Ballpoint Pen Ink*	

Guide refers to performance tests conducted in laboratory conditions. While the foregoing instructions have proven to work in many cases, especially in which ink stains are addressed immediately, not all ink stains can be removed. This information does not guarantee the user from the responsibility of the correct and safe use of product and referenced cleaning agents. Product may not protect against intentional stains or permanent inks.

***PLEASE NOTE:** A variety of clothing and accessories may contain dyes that could transfer to lighter colors, depending upon variations in temperature and humidity. Dye transfer is difficult to control, not always fully preventable, and may be irreversible. Ultrafabrics, LLC assumes no responsibility and can not be held liable for dye transfer caused by external contaminants.

For more information, please visit us on the web at www.ultrafabricsllc.com